



INSTRUCTIONS

RIGHT ANGLE CONNECTION

1



REMOVE THE SCREW
AND END CAP
FROM THE CONNECTOR

2



CUT THE CABLE TO THE
DESIRED LENGTH WITH A SHARP BLADE
MAKING SURE THE CUT IS CLEAN AND STRAIGHT

3



PUSH THE CABLE FIRMLY
INTO THE CONNECTOR

4



BEND THE CABLE 90 DEGREES
AND REPLACE THE END CAP

5



INSERT THE SCREW AND TIGHTEN
KEEPING PRESSURE ON THE CABLE

6



REPEAT FOR THE OTHER
END OF THE CABLE

STRAIGHT CONNECTION

FOLLOW STEPS 1 AND 2 ABOVE
THEN FEED THE END CAP ONTO THE CABLE
AND PUSH THE CABLE END FIRMLY
INTO THE CONNECTOR

SLIDE THE END CAP ONTO THE CONNECTOR MAKING
SURE TO LINE UP THE SCREW HOLE, ALLOWING THE
CAP TO COVER THE RIGHT ANGLE CABLE SLOT.
INSERT SCREW AND TIGHTEN

